

# ROLSEN RC-1153038 [TV]

Parašė

Trečiadienis, 04 Vasaris 2009 18:59 - Atnaujinta Penktadienis, 16 Sausis 2015 22:39

---



<b>TIPAS:</b>	□ □ □ □ □ □ NV pultas □ ROLSEN RC-1153038 [TV]
---------------	--

<b>KAINA:</b> □	□ □ □ □ □ □ □ □ □ □	<b>(nėra prekyboje)</b>
-----------------	---------------------	-------------------------

<b>MIKROSCHEMA:</b>	□ □ □ □ □ □ □ □ S3C1850DD2SNB1
---------------------	--------------------------------

<b>APARATŪROS MODELIAI:</b> □ □ □ □
-------------------------------------

□ □ □ □ □ □ □ □ C2165 C21R60 □ □ □ C21R65 □ □ □ □ TVC160
--

# ROLSEN RC-1153038 [TV]

Parašė

Trečiadienis, 04 Vasaris 2009 18:59 - Atnaujinta Penktadienis, 16 Sausis 2015 22:39

---

<b>PULTO ANALOGAI:</b>	□ □ □ □	□
------------------------	---------	---

□ □ □	□ HORIZONT RC-1153038	AKAI RC-1153012 □
-------	-----------------------	-------------------

□ □ □ □ HORIZONT RC-1153038	POBARS RC-1153012
-----------------------------	-------------------

□ □ □ □ HORIZONT	RC-1153035	
------------------	------------	--

## **ROLSEN RC-1153038 [TV]**

Parašė

Trečiadienis, 04 Vasaris 2009 18:59 - Atnaujinta Penktadienis, 16 Sausis 2015 22:39

---