

# TELEFUNKIN RC100 [TV]

Parašė

Trečiadienis, 04 Vasaris 2009 18:59 - Atnaujinta Penktadienis, 16 Sausis 2015 22:57

---



<b>TIPAS:</b>	□ □ □ □ □ □ NV pultas	□ TELEFUNKIN RC100 [TV]
---------------	-----------------------	-------------------------

<b>KAINA:</b> □	□ □ □ □ □ □ □ □ □ □	<b>nėra prekyboje</b>
-----------------	---------------------	-----------------------

<b>MIKROSCHEMA:</b>	□ □ □ □ □ □ □ □ 20752980CP00
---------------------	------------------------------

<b>APARATŪROS MODELIAI:</b>	□ DF316ET □ □	□ DF321C □ □ DF321E □	□ DF322E □
-----------------------------	---------------	-----------------------	------------

□ DF322E □ DF416ET	□ DF421C □ DF421E □ □ DF422C □ □ DF422E □ □ DF440E
--------------------	--

# TELEFUNKIN RC100 [TV]

Parašė

Trečiadienis, 04 Vasaris 2009 18:59 - Atnaujinta Penktadienis, 16 Sausis 2015 22:57

---

**DS521E DS521EF MA110C MA111C MA115CG MA115GT MA116CG**

**MA116GT MA211C MA216CG MA216GT MF210C MF215CG**

<b>MF215GT</b>	<b>MF218C</b>	<b>MF221C</b>	<b>MF222C</b>
----------------	---------------	---------------	---------------

<b><u>PULTO ANALOGAI:</u></b>			<b>RCT100</b>	
-------------------------------	--	--	---------------	--

## TELEFUNKIN RC100 [TV]

Parašė

Trečiadienis, 04 Vasaris 2009 18:59 - Atnaujinta Penktadienis, 16 Sausis 2015 22:57

---